





Polaris Predator and Outlaw Axle Wheel Hub Installation Details

Your wheel hubs need to be installed as shown below. Note we include special washers so you can run your wheel hubs narrower, so the hub won't wear out prematurely with the thin surface area of the adjustment spacer. Always check to make sure the wheel hubs aren't loose.





LONE STAR RACING - 1424 E. BROADWAY RD. PHOENIX, AZ 85040
1-800-4LS-RACE WWW.LSRACING.COM



Polaris Predator and Outlaw Axle Wheel Hub Installation Details

Your wheel hubs need to be installed as shown below. Note we include special washers so you can run your wheel hubs narrower, so the hub won't wear out prematurely with the thin surface area of the adjustment spacer. Always check to make sure the wheel hubs aren't loose.



LONE STAR RACING - 1424 E. BROADWAY RD. PHOENIX, AZ 85040
1-800-4LS-RACE WWW.LSRACING.COM